1999 ford mustang owners manual

Download

Download

Quick Links. See also: Workshop Manual. Table of Contents. Before driving. Controls And Features. Seating And Safety Restraints. Starting and driving. Roadside Emergencies. Maintenance And Care. Capacities And Specifications. Customer Assistance. Reporting Safety Defects. All rights reserved. Reproduction by any means, electronic. Ford motor company ford f owner's guide 14 pages. Ford motor company ford contour owner's guide pages. Automobile Ford Escort Owner's Manual Ford motor company ford escort owner's guide pages. Ford motor company ford f owner's guide pages. Ford motor company ford crown victoria owner's guide pages. Ford motor company ford explorer owner's guide pages. Ford motor company ford ranger owner's guide pages. Ford motor company mark viii owner's guide pages. Reproduction by any means, electronic or mechanical including photocopying, recording or by any information storage and retrieval system or translation in whole or part is not permitted without written authorization from Ford Motor Company. Copyright Ford Motor Company Contents Read the following section on Warnings. Indicates vehicle information related to recycling and other environmental concerns will follow. Correct vehicle usage and the authorized disposal of waste cleaning and lubrication materials are significant steps towards protecting the environment. Ford may change the contents without notice and without incurring obligation. Page 4: Instrumentation Instrumentation Headlamp control pg. If one or both of the indicators stay on continuously or flash faster, check for a burned-out turn signal bulb. Page 7 Instrumentation High beams Illuminates when the high beam headlamps are turned on. Safety belt Momentarily illuminates when the ignition is turned to the ON position to remind you to fasten your safety belts. For more information, refer to the Seating and safety restraints chapter. Charging system Illuminates when the ignition is turned to The OBD II system protects the environment by ensuring that your vehicle continues to meet government emission standards. No additional vehicle service is required. If the Service Engine Soon light remains on, have your vehicle serviced at the first available opportunity. Light is blinking: Engine misfire is occurring which could damage your catalytic converter. It also illuminates when the Traction Control system begins applying and releasing the brakes and adjusting the engine characteristics to limit a wheelspin condition. It will be lit for a minimum of four seconds or for the duration of the Traction Control event. Page Headlamps On Warning Chime and more needs to be added. This lamp will also illuminate when the ignition is turned to ON and the engine is off. For more information on adding engine coolant, refer to Engine coolant in the Maintenance and care chapter. Safety belt warning chime Chimes to remind you to fasten your safety belts. Page Fuel Gauge Instrumentation Optional instrument cluster gauges Fuel gauge Displays approximately how much fuel is in the fuel tank when the key is in the ON position. The fuel gauge may vary slightly when the vehicle is in motion. The ignition should be in the OFF position while the vehicle is being refueled. Page The Vehicle Never remove the coolant reservoir cap while the engine is running or hot. This gauge indicates the temperature of the engine coolant, not the coolant level. If the coolant is not at its proper level the gauge indication will not be accurate. Page Trip Odometer Instrumentation Tachometer Indicates the engine speed in revolutions per minute. Driving with your tachometer pointer at the top of the scale or in the red zone may damage the engine. Base instrument cluster Standard instrument cluster Trip odometer Registers the kilometers miles of individual journeys. Page 15 Battery voltage gauge This gauge shows the battery voltage when the ignition is in the ON position. Engine oil pressure gauge This shows the engine oil pressure in the Pull the headlamp control toward you to the outer position to turn on the headlamps in addition to the previous lamps. To turn on the courtesy lamps: Rotate fully counterclockwise. Temperature control knob Controls the temperature of the airflow inside the vehicle. Mode selector control Controls the direction of the airflow to the inside of the vehicle. In snowy or dirty conditions, leave the mode selector in the OFF position when the ignition is turned off. Page 20 Controls and features the windshield defroster ducts. It can be used to clear ice or fog from the windshield. Page Volume Control top of your instrument panel. These objects can fall down into the defroster outlets and block airflow and possibly damage your climate control system. Do not place objects on top of the instrument panel, as these objects may become projectiles in a collision or sudden stop. Tune adjust in radio mode Tune adjust allows you to tune in a particular radio station. Page 23 Seek function in tape mode The Automatic Music Search AMS feature allows you to quickly locate the beginning of the tape selection being played or to skip to the next selection. Press the AMS control. Press to listen to the previous selection on the tape. Page 24 Controls and features Setting memory preset stations 1. Select a station. Refer to Tune adjust or Seek function for more information on selecting a station. Press and hold a memory preset control until the sound returns, indicating the station is Speaker balance adjust Speaker sound distribution can be adjusted between the right and left speakers. Play will continue once the beginning of the tape is reached or rewind is stopped. Press to fast forward the tape. Volume control Press the control to raise or lower

volume. Page 28 Controls and features Tune adjust Tune adjust works in radio mode and allows you to manually tune in a particular radio station. The display reads TUNE. Press the SEEK control to move up or down through the frequencies. Page 29 Press to listen to the next selection on the tape. Scan function The scan function works in radio, tape and CD mode if equipped. Scan function in radio mode This feature allows you to scan the frequency band, stopping on each listenable station for approximately a five-second sampling. Page 30 Controls and features Press to scan forward selections. Radio station memory preset The radio is equipped with five station memory preset controls. Page 32 Controls and features Tape play select Insert a cassette tape into the cassette deck. Push only slightly when inserting a cassette tape with the open edge to the right. A cassette deck loading mechanism pulls the tape in the rest of the way. Press to set the hours. Press to set the minutes. Page 34 Controls and features wish to maintain your preset volume level, turn the audio system off with the power control before switching off the ignition. Page 35 Seek function in radio mode Press to find the next listenable station down the frequency band. Press to find the next listenable station up the frequency band. Scan function The scan function works in radio mode. Press and hold a memory preset control until the sound returns, indicating the station is held in memory on the control you selected. If the battery is disconnected, the memory preset stations will need to be reset. Automatic memory store if equipped Automatic memory store allows you to set strong radio stations without losing your original manually Speaker fade adjust Speaker sound distribution can be adjusted between the front and rear speakers. Page 38 Controls and features Press the control for more than three seconds for fast forward action. CD eject Press the control to stop and eject a CD. If a disc is ejected from the CD player but is not removed within approximately 10 seconds, the player will automatically reload the disc for storage unless the disc is automatically ejected because it was inserted upside down, in which case the disc The CD player will begin scanning the CD, stopping on each listenable track for approximately eight seconds. Page 41 Compression adjust brings soft and loud CD passages together for a more consistent listening level. Shuffle feature The shuffle feature plays all tracks on the current CD in random order. Random order play will continue until the control is pressed again. Allow the player to cool down before operating. A disc with format and dimensions not within industry standards is inserted. Cleaning compact discs Inspect all discs for contamination before playing. If necessary, clean discs only with an approved CD cleaner and wipe from the center out to the edge. If service is necessary, see your dealer or a qualified technician. Page 45 Mist Function To operate the Mist function of the windshield wipers, push and release the windshield washer control quickly. The wipers will cycle one or two times. Page 46 Controls and features 5. START, cranks the engine. Release the key as soon as the engine starts. Hold the control while adjusting the wheel to the desired position, then release the Once speed control is switched off, the previously programmed set speed will be erased. For speed control to operate, the speed control must be ON and the vehicle Each press will increase the set speed by 1. Page 49 To disengage speed control Depress the brake pedal or Depress the clutch pedal if equipped Disengaging the speed control will not erase the previously programmed set speed. Pressing OFF will erase the previously programmed set speed. Press the controls on either side of each map lamp to activate the lamps. Page 51 Controls and features Express down To make the driver window open fully without holding the window control, press the driver window control completely down and release quickly. Depress again to stop window operation. Window lock The window lock feature allows only the driver to operate the power windows. Page 52 Controls and features 2. Move the control in the direction you wish to tilt the mirror. Return to the center position to lock mirrors in place. Page 53 Controls and features Foglamp control if equipped Turn on the parking lamps or the low-beam headlamps. Press the top portion of the foglamp control, located on the center console, to activate the foglamps. The foglamp LED will illuminate when the foglamps are on. Press the bottom portion of the foglamp control to deactivate the foglamps. Page 54 Controls and features 2. Check the convertible top stowage compartment behind the rear seat to be sure it is empty and ready to receive the top. Unclamp the top from the windshield header at both the right and left sides by pulling each clamp rearward until the hook in the windshield header is free. Page 55 Controls and features 2. Push boot forward until rear attachment engages under molding. Push forward flap of boot until both clips engage under trim panel edge. Repeat on other side of vehicle. Tuck side attachments under molding. Page 56 Controls and features Raising the convertible top The convertible top will not operate unless the parking brake is engaged. Do not raise the top while the vehicle is moving because the top may be severely damaged. To raise the convertible top: 1. The remote entry features only operate with the ignition in the OFF position. If there is any potential remote keyless entry problem with your vehicle, ensure ALL key fobs remote entry transmitters are brought to the dealership, to aid in troubleshooting. Page 58 Controls and features Opening the trunk Press

the control once to open the trunk. Ensure that the trunk is closed and latched before driving your vehicle. Failure to latch the trunk may cause objects to fall out of the trunk or block the rear view. Sounding a panic alarm Press this control to activate the alarm. Page 59 The inside lights will not turn off if: they have been turned on with the dimmer control or any door is open. The battery saver will shut off the interior lamps 30 minutes after the ignition has been turned to the OFF position, 10 minutes after if the door is left open, and 30 minutes after if the trunk is left open or the dome lamp switch is left on. Page 60 Controls and features weather conditions nearby radio towers structures around the vehicle other vehicles parked next to the vehicle To replace the batteries: 1. Twist a thin coin between the two halves of the transmitter near the key ring. Page 61 The SecuriLock compatible with aftermarket remote start systems. Use of these systems may result in vehicle starting problems and a loss of security protection. Large metallic objects or devices such as the Mobil Speedpass on the same key ring as your SecuriLock key may cause vehicle starting problems. Page 62 Controls and features Programming spare SecuriLock Spare SecuriLock your dealership and programmed to your SecuriLock passive anti-theft system up to a total of 8 keys. Your dealership can program your new SecuriLock key s to your vehicle or you can do it yourself using the following simple procedure. Page 63 4. The purpose of these head restraints is to help limit head motion in the event of a rear collision. To properly adjust your head restraints, lift the head restraint so that it is located directly behind your head or as close to that position as possible. Page 65 Seating and safety restraints Lift handle to move seat forward or backward. Pull lever up to adjust seatback. Do not pile cargo higher than the seatbacks to avoid injuring people in a collision or sudden stop. Page 66 Seating and safety restraints Press to raise or lower the front portion of the seat cushion. Press to raise or lower the rear portion of the seat cushion. Press the control to move the seat forward, backward, up or down. Using the power lumbar support if equipped The power lumbar control is located on Move the control up to increase firmness and down to decrease firmness. To lower the seatback s from inside the vehicle, pull tab to release seat back and then fold seatback down. Page 69 Seating and safety restraints It is extremely dangerous to ride in a cargo area, inside or outside of a vehicle. In a collision, people riding in these areas are more likely to be seriously injured or killed. Do not allow people to ride in any area of your vehicle that is not equipped with seats and safety belts. Page 70 Seating and safety restraints 1. Insert the belt tongue into the proper buckle the buckle closest to the direction the tongue is coming from until you hear a snap and feel it latch. Make sure the tongue is securely fastened in the buckle. Page 71 Seating and safety restraints The automatic locking mode is not available on the driver safety belt. Anytime a child safety seat is installed in a passenger front or outboard rear seating position if equipped. Page 72 Seating and safety restraints Allow the belt to retract. As the belt retracts, you will hear a clicking sound. This indicates the safety belt is now in the automatic locking mode. Page 73 if equipped , child safety seat tether bracket assemblies if equipped , and attaching hardware, should be inspected after a collision. Ford recommends that all safety belt assemblies used in vehicles involved in a collision be replaced. However, if the collision was minor and a Page 74 Seating and safety restraints Failure to inspect and if necessary replace the safety belt assembly under the above conditions could result in severe personal injuries in the event of a collision. Refer to Cleaning and maintaining the safety belts in the Maintenance and care section. Always transport children 12 years old and under in the back seat and always properly use appropriate child restraints. Page 76 Seating and safety restraints Do not attempt to service, repair, or modify the Air Bag Supplemental Restraint System or its fuses. See your Ford or Lincoln-Mercury dealer. Children and air bags For additional important safety information, read all information on safety restraints in this guide. Page 77 Seating and safety restraints How does the air bag supplemental restraint system work? The air bag SRS is designed to activate when the vehicle sustains longitudinal deceleration sufficient to cause the sensors to close an electrical circuit that initiates air bag inflation. Page 78 Seating and safety restraints considerable force, there is the risk of death or serious injuries such as fractures, facial and eye injuries or internal injuries, particularly to occupants who are not properly restrained or are otherwise out of position at the time of air bag deployment. Thus, it is extremely important that occupants be properly restrained as far away from the air bag module as possible while maintaining vehicle control. Page 79 Seating and safety restraints A difficulty with the system is indicated by one or more of the following: The readiness light will either flash or stay lit. The readiness light will not illuminate immediately after ignition is turned on. A series of five beeps will be heard. The tone pattern will repeat periodically until the problem and light are repaired. Page 80 Do not leave children, unreliable adults, or pets unattended in your vehicle. To improve the fit of lap and shoulder belts on children who have outgrown child safety seats, Ford recommends use of a belt-positioning booster seat that is labelled as conforming to all Federal motor Page 81 Seating and safety restraints seats raise the child and provide a

shorter, firmer seating cushion that encourages safer seating posture and better fit of lap and shoulder belts on the child. Page 82 Refer to Automatic locking mode passenger side front and outboard rear seating positions if equipped. Ford recommends the use of a child safety seat having a top tether strap. Install the child safety seat in a seating position which is capable of providing a tether anchorage. Page 83 Seating and safety restraints Installing child safety seats in combination lap and shoulder belt seating positions If you must use a forward facing child seat in the front seat reminder children 12 years old and unders should always be properly restrained in the rear seat. Page 84 Seating and safety restraints 3. Be sure the belt webbing is not twisted. Insert the belt tongue into the proper buckle the buckle closest to the direction Page 85 Tether anchorage hardware Attachment holes at each rear seating position have been provided in your vehicle to attach anchor hardware, if desired. Tether anchorage hardware kits part number D74 including instructions, may be obtained at no charge from any Ford or Page 86 Seating and safety restraints Lincoln-Mercury dealer. All vehicles built for sale in Canada include a tether anchor hardware kit. Tighten the anchor according to specifications. Otherwise, the safety seat may not be properly secured and the child may be injured in a sudden stop or collision. This system meets all Canadian Interference-Causing Equipment standard requirements regulating the impulse electrical field strength of radio noise. When starting a fuel-injected engine, avoid pressing the accelerator before or during starting. Only use the accelerator when you have difficulty starting the engine. When the engine starts, the idle RPM runs faster to warm the engine. If the engine idle speed does not slow down automatically, have the vehicle checked. Do not allow the vehicle to idle for more than ten minutes at high engine RPM. Page 89 3. Make sure the corresponding lights illuminate briefly. If a light fails to illuminate, have the vehicle serviced. Turn the key to 5 START without pressing the accelerator pedal and release as soon as the engine starts. The key will return to 4 ON. Page 91 Guarding against exhaust fumes Although odorless and colorless, carbon monoxide is present in exhaust fumes. Take precautions to avoid its dangerous effects. If you ever smell exhaust fumes of any kind inside your vehicle, have your dealer inspect and fix your vehicle immediately. Do not drive if you smell exhaust fumes. Refer to the scheduled maintenance guide for scheduled maintenance. In normal operation, automotive brake systems may emit occasional or intermittent squeal or groan noises when the brakes are applied. Page 93 The ABS operates by detecting the onset of wheel lockup during brake applications and compensating for this tendency. The wheels are prevented from locking even when the brakes are firmly applied. The accompanying illustration depicts the advantage of an ABS equipped vehicle on bottom to a non-ABS equipped vehicle on top during hard braking with loss of front braking traction. Page 94 Driving stopping distance. Always leave enough room between your vehicle and the vehicle in front of you to stop. We recommend that you familiarize yourself with this braking technique. However, avoid taking any unnecessary risks. Hydraulic brake booster system Hydroboost The Hydroboost system receives fluid pressure from the power steering pump to provide power assist during braking. Page 95 when the ignition is turned ON until the parking brake is released. Always set the parking brake fully and make sure that the gearshift is securely latched in P Park automatic transmission or in 1 First Gear manual transmission. The parking brake is not recommended to stop a moving vehicle. Page 96 Driving controlled by automatically applying and releasing the rear brakes in conjunction with engine torque reductions. Engine torque reduction is realized via the fully electronic spark and fuel injection systems. This process is very sensitive to driving conditions and very fast acting. Page 97 To prevent damage to the power steering pump: Never hold the steering wheel to the extreme right or the extreme left for more than a few seconds when the engine is running. Do not operate the vehicle with a low power steering pump fluid level. Page 98 Driving Do not drive your vehicle until you verify that the brakelamps are working. If your vehicle gets stuck in mud or snow it may be rocked out by shifting from forward and reverse gears, stopping between shifts, in a steady pattern. Press lightly on the accelerator in each gear. Make sure the gearshift is securely latched in P Park. This position locks the transmission and prevents the rear wheels from turning. Always set the parking brake fully and make sure the gearshift is securely latched in P Hold the brake pedal down while in this gear. Overdrive The normal driving position for the best fuel economy. Transmission operates in gears one through four. Page instrument cluster. Transmission operates in gears one through three. If towing a trailer, refer to Driving while you tow in the Trailer Towing chapter. When starting a vehicle with a manual transmission, you must: 1. This will damage the clutch. Upshift according to the following chart: Upshifts when accelerating recommended for best fuel economy 1 - 2 2 - 3 3 - 4 4 - Page Driving 4. Turn the ignition key to position 3 OFF. Do not park your vehicle in Neutral, it may move unexpectedly and injure someone. Use 1 First gear and set the parking brake fully. Reverse You can shift into R Reverse only by moving the gearshift to the right of 5 Fifth gear before you shift into R Reverse. Page

gearshift back into Neutral. Then, release the clutch pedal for a moment and repeat steps 2 through 4. Removing key from ignition Turn the ignition key to position 3 OFF. Push the release lever forward and rotate the key towards you and remove. It does not include passengers or aftermarket equipment. Payload: Combined maximum allowable weight of cargo, passengers and optional equipment. Page Maximum Trailer Weight: maximum weight of a trailer the loaded vehicle including passengers and cargo is permitted to tow. It is determined by subtracting the weight of the loaded trailer towing vehicle from the GCWR for the towing vehicle. Trailer Weight Range: Specified weight range that the trailer must fall within that ranges from zero to the maximum trailer weight rating. Page Driving Always ensure that the weight of passengers, cargo and equipment being carried is within the weight limitations that have been established for your vehicle including both Gross Vehicle Weight and Front and Rear Gross Axle Weight Rating limits. Under no circumstance should these limitations be exceeded. Page If you use a rental trailer, follow the instructions that the rental agency gives to you. Do not attach safety chains to the bumper. Servicing after towing If you tow a trailer for long distances, your vehicle will require more frequent service intervals. Refer to your Scheduled Maintenance guide for more information. Traction or brake capability may be limited and if the ignition system gets wet, your engine may stall. The hazard flashers can be operated when the ignition is off. The hazard lights control is located on top of the steering column. Page Use the following procedure to reset the fuel pump shut-off switch. Turn the ignition to the OFF position. Check the fuel system for leaks. If no fuel leak is apparent, reset the fuel pump shut-off switch by pushing in on the reset button. Always disconnect the battery before servicing high current fuses. Always replace the cover to the Power Distribution Box before reconnecting the battery or refilling fluid reservoirs. Instead, gradually decrease your speed. Hold the steering wheel firmly and slowly move to a safe place on the side of the road. Page Roadside emergencies Temporary spare tire information Your vehicle may have a temporary spare tire. The temporary spare tire for your vehicle is labeled as such. It is smaller than a regular tire and is designed for emergency use only. Replace this tire with a full-size tire as soon as possible. Page Roadside emergencies 1. Park on a level surface, activate hazard flashers and set parking brake. Remove the spare tire, jack and lug wrench. Page Roadside emergencies Never use the rear differential as a jacking point. To lessen the risk of personal injury, do not put any part of your body under the vehicle while changing a tire. Do not start the engine when your vehicle is on the jack. Page not the dealer to get a replacement key. Do not use an impact wrench with the anti-theft key. Page Roadside emergencies Do not push start your vehicle. You could damage the catalytic converter. Batteries contain sulfuric acid which can burn skin, eyes, and clothing, if contacted. Do not attempt to push start your vehicle. Automatic transmissions do not have push-start capability. Page Roadside emergencies Connecting the jumper cables 1. Note: In the illustrations, lightning bolts are used to designate the assisting boosting battery. Page Roadside emergencies 4. The preferred locations of an exposed metal part to ground the circuit are the alternator mounting brackets or an engine lifting eye. Page Roadside emergencies Removing the jumper cables Remove the jumper cables in the reverse order that they were connected. Remove the jumper cable from the ground metal surface. After the disabled vehicle has been started and the jumper cables removed, allow it to idle for several minutes so the engine computer can relearn its idle conditions. Page It is recommended that your vehicle be towed with a wheel lift or flatbed equipment. Do not tow with a slingbelt. Ford Motor Company has not approved a slingbelt towing procedure. If your vehicle is to be towed from the rear using We provide a Scheduled Maintenance Guide which makes tracking routine service easy. If your vehicle requires professional service, your dealership can provide necessary parts and service. Page 2. Turn off the engine and remove the key. Block the wheels to prevent the vehicle from moving unexpectedly. Manual transmission: 1. Set the parking brake. Depress the clutch and place the gearshift in 1 First. Inside the vehicle, pull the hood release handle located under the bottom left corner of the instrument panel. HOOD 2. Go to the front of the vehicle and release the auxiliary latch that is located under the front center of the hood. Engine oil filler cap 2. Engine oil dipstick 3. Brake fluid reservoir 4. Power distribution box 5. Windshield washer fluid reservoir 6. Battery 7. Power steering fluid reservoir 8. Page Maintenance and care 4. Engine oil dipstick 2. Brake fluid reservoir 3. Power distribution box 4. Windshield washer fluid reservoir 5. Battery 6. Engine coolant reservoir 7. Engine oil filler cap 9. Turn the engine off and wait a few minutes for the oil to drain into the oil pan. Set the parking brake and ensure the gearshift is securely latched in P Park automatic transmissions or 1 First manual transmissions. Oil levels above the MAX mark may cause engine damage. Some oil must be removed from the engine by a service technician. Page Ford material and design specifications, startup engine noises or knock may be experienced. It is recommended you use the appropriate Motorcraft oil filter or another brand meeting Ford specifications for your engine application. Page 3. If

necessary, add brake fluid until the level reaches MAX. Do not fill above this line. Use only a DOT 3 brake fluid certified to meet Ford specifications. Refer to Lubricant specifications in the Capacities and specifications chapter. Page Brake fluid is toxic. If you use a brake fluid that is not DOT 3, you will cause permanent damage to your brakes. Do not let the reservoir for the master cylinder run dry. This may cause the brakes to fail. The reservoir is highlighted with a symbol. If the level is low, add enough fluid to fill the reservoir. In very cold weather, do not fill the reservoir all the way. Refer to the Scheduled Maintenance Guide for service interval schedules. Be sure to read and understand Precautions when servicing your vehicle in this chapter. If the engine coolant has not been checked at the recommended interval, the engine coolant reservoir may become empty. Page Change your engine coolant according to the appropriate schedule listed in the Scheduled Maintenance Guide. Recycled engine coolant Ford Motor Company recommends that Ford and Lincoln-Mercury dealers use recycled engine coolant produced by Ford-approved processes. Page Maintenance and care Always dispose of used automotive fluids in a responsible manner. Start the engine and let it run until it reaches normal operating temperature the engine coolant temperature gauge indicator will be near Page Maintenance and care If your vehicle is equipped with a 4. Allow at least one-half hour after driving for the power steering fluid to cool. Start the engine and allow the engine to idle. Page Maintenance and care been operated for an extended period at high speeds, in city traffic during hot weather or pulling a trailer, the vehicle should be turned off for about 30 minutes to allow fluid to cool before checking. Drive the vehicle 30 km 20 miles or until it reaches normal operating temperature. Page Maintenance and care could result when the vehicle reaches normal operating temperature. High fluid level Fluid levels above the safe range may result Page 4. Add enough fluid through the filler opening so that the fluid level is at the bottom of the opening. Install and tighten the fill plug securely. Use only fluid that meets Ford specifications. Refer to the Capacities and specifications chapter. However, for severe usage or in high temperature climates, check the battery electrolyte level. Refer to the Scheduled Maintenance Guide for the service interval schedules. Page Batteries normally produce explosive gases which can cause personal injury. Therefore, do not allow flames, sparks or lighted substances to come near the battery. When working near the battery, always shield your face and protect your eyes. Always provide proper ventilation. When lifting a plastic-cased battery, excessive pressure on the end walls could cause acid to flow through the vent caps, resulting The relearning process will automatically complete as you drive the vehicle. The vehicle may need to be driven 16 km 10 miles or more to relearn the idle and fuel trim strategy. If you do not allow the engine to relearn its idle trim, the idle quality of your vehicle may be adversely affected until the idle trim is eventually relearned. Department of Transportation-Tire quality grades: The U. Department of Transportation requires Ford to give you the following information Page Treadwear Maintenance and care about tire grades exactly as the government has written it. Treadwear The treadwear grade is a comparative rating based on the wear rate of the tire when tested under controlled conditions on a specified government test course. Grades B and A represent higher levels of performance on the laboratory test wheel than the minimum required by law. The temperature grade for this tire is established for a tire that is properly inflated and not overloaded. Page Maintenance and care 15 or 16 inch four tire rotation 17 inch four tire rotation Replacing the tires Replace the tires when the wear band is visible through the tire treads. Page Make sure that all replacement tires are of the same size, type, load-carrying capacity and tread design e. Failure to follow these precautions may adversely affect the handling of the vehicle and make it easier for the driver to lose control and roll over. Page Maintenance and care The tires on your vehicle have all weather treads to provide traction in rain and snow. However, in some climates, you may need to use snow tires and chains. Use chains on the tires only in an emergency or if the law requires them. Page The fuel system may be under pressure. If the fuel filler cap is venting vapor or if you hear a hissing sound, wait until it stops before completely removing the fuel filler cap. Otherwise, fuel may spray out and injure you or others. If you do not use the proper fuel filler cap, excessive pressure or vacuum in the fuel tank may damage the fuel system or cause the fuel Page Maintenance and care Avoid getting fuel liquid in your eyes. If fuel is splashed in the eyes, remove contact lenses if worn , flush with water for 15 minutes and seek medical attention. Failure to seek proper medical attention could lead to permanent injury. Fuels can also be harmful if absorbed through the skin. Page The customer warranty may be void for any damage to the fuel tank or fuel system if the correct genuine Ford or Motorcraft fuel filler cap is not used. The fuel system may be under pressure. Page Maintenance and care If you do not use the proper fuel filler cap, excessive pressure or vacuum in the fuel tank may damage the fuel system or cause the fuel system to work improperly in a collision, which may result in possible personal injury. Running out of fuel Avoid running out fuel because this situation may have an adverse affect on powertrain

components. You must gather information as accurately and consistently as possible. Fuel expense, frequency of fillups or fuel gauge readings are NOT accurate as a measure of fuel economy. Page Use a known quality gasoline, preferably a national brand. Use the same side of the same pump and have the vehicle facing the same direction each time you fill up. Have the vehicle loading and distribution the same every time. Your results will be most accurate if your filling method is consistent. Page Maintenance and care Driving style â€" good driving and fuel economy habits Give consideration to the lists that follow and you may be able to change a number of variables and improve your fuel economy. Page Combine errands and minimize stop-and-go driving. Maintenance Keep tires properly inflated and use only recommended size. Operating a vehicle with the wheels out of alignment will reduce fuel economy. Use recommended engine oil. Refer to Lubricant Specifications. Perform all regularly scheduled maintenance items. Page If other than Ford, Motorcraft or Ford-authorized parts are used for maintenance replacements or for service of components affecting emission control, such non-Ford parts should be equivalent to genuine Ford Motor Company parts in performance and durability. Page Do not park, idle, or drive your vehicle in dry grass or other dry ground cover. The emission system heats up the engine compartment and exhaust system, which can start a fire. Grasp the bulb only by its plastic base and do not touch the glass. The oil from your hand could cause the bulb to break the next time the headlamps are operated. Page Maintenance and care To install the new bulb: 1. You may need to turn the bulb left or right to align the grooves in the plastic base with the tabs in the lamp assembly. Page Maintenance and care 5. Carefully pull the bulb straight out from the socket and push in the new bulb. To complete installation, follow the removal procedure in reverse order. Page Maintenance and care 1. Rotate the foglamp bulb counterclockwise and remove from foglamp the rear side of the foglamp is shown. Disconnect the electrical connector from the foglamp bulb. Connect the electrical connector to the new foglamp bulb. Page Map lamps For bulb replacement, see a qualified service technician or your dealer. Using the right bulbs Function Tail lamp, brakelamp, turn lamp Park lamp, turn lamp, side marker front Backup lamp License plate lamp High-mount brakelamp Headlamps Luggage compartment lamp Dome lamp Map lamp Visor vanity lamp Page 6. Close the hood and turn off the lamps. Page Maintenance and care Washing your vehicle Wash your vehicle regularly with cold or lukewarm water. Never use strong detergents or soap. If your vehicle is particularly dirty, use a quality car wash detergent. Always use a clean sponge, washing glove or similar device and plenty of water for best results. Page Cover the highlighted areas to prevent water damage when cleaning the engine. Never wash or rinse the engine while it is running; water in the running engine may cause internal damage. Cleaning plastic exterior parts Use vinyl cleaner for routine cleaning. Clean with a tar remover if necessary. Page Dry with a soft cloth. This mild cleaner and special pad, cleans the leather and maintains its natural beauty. Follow the instructions on the cleaner label. Page Convertible top and padded molding care To avoid damage to the vinyl top and moldings, use only an approved Ford cleaner, or equivalent. Do not use stiff bristle brushes or abrasive materials or cleaners. Hot waxes applied by commercial car washes can affect the cleanability of vinyl material. Refer to Adding engine coolant, in the Maintenance and Care chapter. Rear axle lubricants do not need to be checked or Page Service refill capacity is determined by filling the transmission to the bottom of the filler hole with the vehicle on a level surface. Page Add ml 4 oz. Ford design rear axles contain a synthetic lubricant that does not require changing unless the axle has been submerged in water. Page Capacities and specifications Page Certification Label The engine number the last eight numbers of the vehicle identification number is stamped on the engine block, transmission, frame and transfer case if equipped. Page Customer Assistance 80, km 50, miles on Lincoln vehicles In the United States, you may purchase additional roadside assistance coverage beyond this period through the Ford Auto Club by contacting your Ford or Lincoln-Mercury dealer. Roadside assistance will cover: changing a flat tire Page There are several plans available in various time, distance and deductible combinations which can be tailored to fit your own driving needs. Ford ESP also offers reimbursement benefits for towing and rental coverage. In Hawaii, rules vary. See your dealer for details. Page Ford. At Ford Motor Company and Ford of Canada, we are dedicated to providing Ford, Lincoln and Mercury vehicle owners with programs that will enhance your ownership experience and protect you from unexpected repair bills. Page Customer assistance general manager of the dealership. In most cases, your concern will be resolved at this level. Ford Motor Company and Ford of Canada dealerships also carry genuine Ford parts and accessories, providing you with original equipment reliability. Away from home The dealership Board member is chosen from Ford and Lincoln-Mercury dealership management, recognized for their business leadership qualities. To properly review your case, the Board needs the The decisions of the Board are binding on Ford and, in some cases, on the dealer but not on consumers who are free to pursue other remedies available to

them under state or federal law. In the United States, using leaded fuel may also result in difficulty importing your vehicle back into the U. For best results, use the following or products of equivalent quality Ford accessories are warranted for up to 12 months or 20, km 12, miles on all cars and light trucks and 12 months with unlimited distance on Page Customer assistance Travel equipment Console Console armrest Daytime running lights Factory luggage rack Factory luggage rack adaptors Fog lights Framed luggage covers Heavy-duty battery Neutral towing transfer case kit Explorer 4. Ford cannot assume responsibility for any adverse effects or damage that may result from the use of such equipment. Page Monday-Friday a. Service Publications P. If NHTSA receives similar complaints, it may open an investigation, and if it finds that a safety defect exists in a group of vehicles, it may order a recall and remedy campaign. Page Index Air bag supplemental restraint system Page Page Fluid capacities Page Index Infant seats see Safety seats Page Power distribution box see Fuses Page Index Traction control Pull handle under the left side of the instrument panel. Service refill capacity is determined by filling the transmission to the bottom of the filler hole with the vehicle on a level surface. This manual is also suitable for: mustang gt. Print page 1 Print document pages. Cancel Delete. Sign In OR. Don't have an account? Sign up! Restore password. Upload from disk. Upload from URL. Skip to main content. Email to friends Share on Facebook - opens in a new window or tab Share on Twitter - opens in a new window or tab Share on Pinterest - opens in a new window or tab. Add to Watchlist. People who viewed this item also viewed. Showing Slide 1 of 1 - Carousel. Check if this part fits your vehicle. Contact the seller. Picture Information. Mouse over to Zoom - Click to enlarge. Get the item you ordered or get your money back. Learn more - eBay Money Back Guarantee - opens in new window or tab. Seller information cmymanuals Contact seller. Visit store. See other items More See all. Item Information Condition:. Sign in to check out Check out as guest. Add to Watchlist Remove from watch list. Watch list is full. Longtime Member. Shipping help - opens a layer International Shipping - items may be subject to customs processing depending on the item's customs value. Your country's customs office can offer more details, or visit eBay's page on international trade. Item location:. Newark, Delaware, United States. Ships to:. This amount is subject to change until you make payment. For additional information, see the Global Shipping Program terms and conditions - opens in a new window or tab This amount includes applicable customs duties, taxes, brokerage and other fees. For additional information, see the Global Shipping Program terms and conditions - opens in a new window or tab. Estimated between Thu. Estimated delivery dates - opens in a new window or tab include seller's handling time, origin ZIP Code, destination ZIP Code and time of acceptance and will depend on shipping service selected and receipt of cleared payment - opens in a new window or tab. Delivery times may vary, especially during peak periods. Any international shipping and import charges are paid in part to Pitney Bowes Inc. Learn More - opens in a new window or tab International shipping and import charges paid to Pitney Bowes Inc. Learn More - opens in a new window or tab Any international shipping and import charges are paid in part to Pitney Bowes Inc. Learn More - opens in a new window or tab Any international shipping is paid in part to Pitney Bowes Inc. Learn More - opens in a new window or tab. Sponsored items from this seller. Showing Slide 1 of 2 - Carousel. Report item - opens in a new window or tab. This translation tool is for your convenience only. The accuracy and accessibility of the resulting translation is not guaranteed. Note: The accuracy and accessibility of the resulting translation is not guaranteed. Seller assumes all responsibility for this listing. Search within store. If you are the winning bidder, you will enter into a legally biding contract to purchase the item. If the seller is unable to establish contact with the winning bidder within 3 days of the end of the auction or if payment is not received within 10 days, item may be offered to the next highest bidder or relisted at the sellers sole discretion. Shipping Details: All shipping originates from the zip code. Shipping and handling. This item will ship to Ukraine , but the seller has not specified shipping options. Contact the seller - opens in a new window or tab and request a shipping method to your location. Shipping cost cannot be calculated. Please enter a valid ZIP Code. Shipping to: Worldwide. No additional import charges at delivery! This item will be shipped through the Global Shipping Program and includes international tracking. Learn more - opens in a new window or tab. There are 1 items available. Please enter a number less than or equal to 1. Select a valid country. Please enter 5 or 9 numbers for the ZIP Code. Domestic handling time. Taxes may be applicable at checkout. Learn more. Return policy. No returns or exchanges, but item is covered by the eBay Money Back Guarantee - opens in a new window or tab. Payment details. Payment methods. Back to home page Return to top. Back to home page. Listed in category:. Email to friends Share on Facebook - opens in a new window or tab Share on Twitter - opens in a new window or tab Share on Pinterest - opens in a new window or tab Add to Watchlist. Image not available Photos not available for this variation. Auction Information. Auction Sales Policy:.

Your bid is a contract - Place a bid only if you're serious about buying the item. Shipping Details:. All shipping originates from the zip code. Payment Details:. See above. The winner will receive an "eBay End of Auction" email. Click on the payment link and follow instructions. Once payment is received, we will ship product. Contact us with any question's:. Privacy Policy:. Rest assured your information will not be given, sold, rented or loaned to any third party. Like the rest of the model year Mustangs, the Mustang GT got a visual upgrade. Gone were many of the soft lines of the early SNs and in was an altogether more aggressive looking muscle car. The GT got the same 4. Now with hp 5, rpm and lbs-ft of torque at 4, rpm it was up from hp and lbs of torque. Ford added new higher lift, longer duration camshafts, bigger valves, improved and increased intake airflow and revised the combustion changers which improves fuel economy, emissions and power. Power is put to the ground via a 5 speed manual transmission that is very positive, but a little notchy. Stopping is done via large 4 wheel discs ventilated front with standard antilock. Ford also did their homework on the chassis dynamics. There were improvements in noise, vibration and harshness NVH and improved steering feel with a turning circle reduction to under 38 feet. The rear track has was widened by 1. On the inside, the Mustang sports a very complete instrument package in a double cowl design. Engines 3. Transmission 5 speed manual 4 speed electronically controlled automatic. Dimensions Wheelbase Share Tweet. Fourth Gen Mustang. See all results. Weekly Mustang News Get the latest Mustang news, rumors, deals and events each week. Cool Mustang stuff. No crap, we promise. This site uses cookies: Find out more. Okay, thanks. This listing is for part or sub-assembly number given below only. Skip to main content. Email to friends Share on Facebook - opens in a new window or tab Share on Twitter - opens in a new window or tab Share on Pinterest - opens in a new window or tab. Add to Watchlist. People who viewed this item also viewed. Showing Slide 1 of 1 - Carousel. Check if this part fits your vehicle. Picture Information. Mouse over to Zoom - Click to enlarge. Trusted seller, fast shipping, and easy returns. Learn more - Top Rated Plus - opens in new window or tab. Seller information quikby Contact seller. Visit store. See other items More See all. Item Information Condition:. Add to Watchlist Remove from watch list. Watch list is full. Last item Available. Shipping help - opens a layer International Shipping - items may be subject to customs processing depending on the item's customs value. Your country's customs office can offer more details, or visit eBay's page on international trade. Item location:. Piqua, Ohio, United States. Ships to:. United States and many other countries See details. This amount is subject to change until you make payment. For additional information, see the Global Shipping Program terms and conditions - opens in a new window or tab This amount includes applicable customs duties, taxes, brokerage and other fees. For additional information, see the Global Shipping Program terms and conditions - opens in a new window or tab. Estimated between Fri. Estimated delivery dates - opens in a new window or tab include seller's handling time, origin ZIP Code, destination ZIP Code and time of acceptance and will depend on shipping service selected and receipt of cleared payment - opens in a new window or tab. Delivery times may vary, especially during peak periods. Seller does not accept returns. Read item description or contact seller for details. See all details Not eligible for eBay purchase protection programs. Sponsored items from this seller. Showing Slide 1 of 2 - Carousel. Report item - opens in a new window or tab. This translation tool is for your convenience only. The accuracy and accessibility of the resulting translation is not guaranteed. Note: The accuracy and accessibility of the resulting translation is not guaranteed. Seller assumes all responsibility for this listing. My Garage. Go to My Garage. Please wait. We were unable to complete your request. Please try again later. This part is not compatible with this. Compatibility information is not available for this item. Oops, something went wrong. This part is compatible with below vehicle s. This part is compatible with below vehicle s matching this. A quantity of 2 is recommended. Portions of the information contained in this table have been provided by quikby. Quikby Garage. Visit my eBay store. Search Store. Items On Sale. We do ship to Alaska and Hawaii. We do ship to international addresses. Please call us to provide credit card information. Payment needs to be received within 24 hours of purchase or the transaction may be canceled. We do charge sales tax in Ohio. State taxes will be calculated at checkout. Buyer pays return shipping. Call ahead to schedule pick-up. Powered by SixBit's eCommerce Solution. Shipping and handling. This item will ship to Ukraine , but the seller has not specified shipping options. Contact the seller - opens in a new window or tab and request a shipping method to your location. Shipping cost cannot be calculated. Please enter a valid ZIP Code. No additional import charges at delivery! This item will be shipped through the Global Shipping Program and includes international tracking. Learn more - opens in a new window or tab. There are 1 items available. Please enter a number less than or equal to 1. Select a valid country. Please enter 5 or 9 numbers for the ZIP Code. Domestic handling time. Taxes may be applicable at checkout. Learn more. Return policy. Feedback on quikby from others who bought

this item. Positive feedback. Back to home page Return to top. Back to home page. Listed in category:. Email to friends Share on Facebook - opens in a new window or tab Share on Twitter - opens in a new window or tab Share on Pinterest - opens in a new window or tab Add to Watchlist. Image not available Photos not available for this variation. Enter your mobile number or email address below and we'll send you a link to download the free Kindle App. Then you can start reading Kindle books on your smartphone, tablet, or computer - no Kindle device required. To get the free app, enter your mobile phone number. Read more Read less. Previous page. Publication date. January 1, See all details. Next page. Kindle Cloud Reader Read instantly in your browser. Register a free business account. Tell the Publisher! I'd like to read this book on Kindle Don't have a Kindle? Fearless and inspiring. Discover Black voices on Audible. Learn more. Customer reviews. How are ratings calculated? Instead, our system considers things like how recent a review is and if the reviewer bought the item on Amazon. It also analyzes reviews to verify trustworthiness. Top reviews Most recent Top reviews. Top review from the United States. There was a problem filtering

abb watermaster wiring diagram
ford ranger service schedule
18 t vacuum diagram

reviews right now. Please try again later. Verified Purchase. We counted the days till it arrived and are so very pleased with it. See all reviews. There's a problem loading this menu right now. Learn more about Amazon Prime. Get free delivery with Amazon Prime. Back to top. Get to Know Us. Amazon Payment Products. English Choose a language for shopping. Amazon Music Stream millions of songs. Amazon Advertising Find, attract, and engage customers. Amazon Drive Cloud storage from Amazon. Alexa Actionable Analytics for the Web. Sell on Amazon Start a Selling Account. AmazonGlobal Ship Orders Internationally. Amazon Rapids Fun stories for kids on the go. ComiXology Thousands of Digital Comics. DPReview Digital Photography. East Dane Designer Men's Fashion. Shopbop Designer Fashion Brands. Deals and Shenanigans. Ring Smart Home Security Systems. PillPack Pharmacy Simplified. Amazon Renewed Like-new products you can trust. Amazon Second Chance Pass it on, trade it in, give it a second life.